

Tyrrells Product Menu

Potatoes

Sweet
Potatoes

Beetroot

Parsnips

Product 5

Product 6

Product 7

Product 8

Press To Save Changes To *Product 8*

Screen Change Screen Change Screen Change Screen Change Screen Change

Left Kettle
Controls

Left Kettle
Speeds

Infeed
Controls

Home

Advanced
Controls

Right Kettle
Speeds

Right Kettle
Controls

PRODUCT MENU

Potatoes	Sweet Potatoes	Beetroot	Parsnips
Product 5	Product 6	Product 7	Product 8
Press To Save Changes To Product X			

This screen is used to instantly change cooking parameters when changing from one product to another.

First, for instance, press the SWEET POTATOES button. This tells the rest of the system to:

- Switch to sweet potato cooking parameters
- Save changes made to the cooking parameters to the SWEET POTATOES menu if the PRESS TO SAVE CHANGES TO SWEET POTATOES button is pressed.

So, now slice in sweet potatoes and begin setting parameters. Any value pertaining to the cooking process can be changed and saved, forming a base set of cooking parameters for sweet potatoes. The screens that hold cooking parameter settings are: INFEEED, KETTLE CONTROLS, SPEED ADJUSTMENTS, CENTRIFUGE CONTROLS, and ADVANCED CONTROLS.

Once all of the parameters are set to your liking press the bar on this screen labelled PRESS TO SAVE CHANGES TO SWEET POTATOES. This will save your cooking parameters to Sweet Potatoes so that the next time you run sweet potatoes you can instantly switch.

Suppose that the next time you run sweet potatoes the raw material is slightly different, and you want to change your slice in temp or your rake out temp. You can change those settings (or any other) to accommodate raw material fluctuations without altering your base set of cooking parameters. Simply change the settings you want to while running, but do not save them to the product menu.